# Performance and Safety Tests of Lithium-ion Cells Arranged in a Matrix Design Configuration

Judith Jeevarajan, Ph.D. NASA-JSC

and

Walt Tracinski, Applied Power International

The 2010 Space Power Workshop April 20-22, 2010

#### Introduction

- Commercial lithium-ion batteries in portable electronic equipment have been used by NASA for space applications since 1999.
- Latest Lenovo Thinkpad Battery has cells in a matrix configuration.
- Used Quallion matrix packs to understand the performance as well as safety
- Test Articles:
  - Two 5X5 Matrix Packs (One with Heat Absorbent Material (HAM) and one without)
  - One 8X8 Matrix Pack (without HAM)

Cells are from Sanyo (cobaltate in the 8X8 and spinels in the 5X5)

- Tests:
  - Short term cycle life: 100 cycles (all three packs)
  - Additional 100 cycles with one cell removed (5X5 packs only)
  - Overcharge Test: 5X5 packs

5X5(no HAM)

External Short: 8X8 pack




5X5(with HAM)




8X8

### Matrix Pack Configuration





Cycle Life Test for 5X5 Lithium-ion Matrix Pack (no HAM)




Discharge: 5A; EODV: 13.5 V


Plots indicate bank to bank variation









### Thermal Profile Trend for 5X5 Lithium-ion Matrix Pack (no HAM)




#### Cycle Life Test for 5X5 Lithium-ion Matrix Pack (with HAM)






Charge: 5 A; EOCV: 21 V Discharge: 5A; EODV: 13.5 V


Plots indicate bank to bank variation




### Thermal Profile Trend for 5X5 Lithium-ion Matrix Pack (with HAM)



### Cycle Life Test for 8X8 Lithium-ion Matrix Pack



### Cycle Life Test for 8X8 Lithium-ion Matrix Pack




### Cell Disconnection from Middle of Cell Bank






### Cycle Life Test for 5X5 Lithium-ion Matrix Pack (no HAM) With One Cell Disconnected Charge: 5 A; EOCV: 21 V



# Cycle Life Test for 5X5 Lithium-ion Matrix Pack (no HAM) With One Cell Disconnected



At 2<sup>nd</sup> Cycle:

Max volt difference: 38 mV

Diff between lower voltage banks


is 25 mV

At 100 cycles:


Max volt difference: 55 mV

Diff between lower voltage banks


is 25 mV




# Temperature Profile for the 1<sup>st</sup> and 100<sup>th</sup> Discharge and Charge Cycle for 5X5 Pack (no HAM) With One Cell Disconnected




Cycle Life Test for 5X5 Lithium-ion Matrix Pack (with HAM) With One Cell Disconnected



Charge: 5 A; EOCV: 21 V Discharge: 5A; EODV: 13.5 V



# Cycle Life Test for 5X5 Lithium-ion Matrix Pack (with HAM) With One Cell Disconnected



Max Volt.: 4.23 V

At 2<sup>nd</sup> Cycle:

Max volt difference: 60 mV

Diff between lower voltage banks


is 40 mV

At 100 cycles:

Max volt difference: 70 mV

Diff between lower voltage banks


is 40 mV




Cycle Life Test for 5X5 Lithium-ion Matrix Pack (with HAM) With One Cell Disconnected

J. Jeevarajan, Ph.D. / NASA-JSC


### Temperature Profile for 5X5 Lithium-ion Matrix Pack (with HAM) With One Cell Disconnected




### Overcharge Test for 5X5 Matrix Pack (no HAM)




## Overcharge Test for 5X5 Matrix Pack (no HAM) (Overcharge at 10 A)




### Overcharge Test for 5X5 Matrix Pack (with HAM)




### Overcharge Test for 5X5 Matrix Pack (with HAM)



#### External Short on 8X8 Matrix Pack



### **External Short on 8X8 Matrix Pack**



### Post- External Short Photo of 8X8 Matrix Pack




#### **Center Bank**





### ISS Lenovo Thinkpad T61P Lithium-ion Battery (Commercial battery pack with Matrix Design Configuration)



#### **Summary and Conclusions**

- Matrix Packs display large variations in cell bank voltages at the charge and discharge current (C/2) used in this test program.
- The voltage difference is larger at the end of discharge than at the end of charge under the conditions studied.
- Disconnection of a cell from the pack leads to a larger voltage difference during discharge (greater than 2.0 V) between the bank that has one less cell and the other banks.
  - Thermal profile does not show any significant changes or increase in temperature after one cell was disconnected from the bank in spite of falling to very low voltages at the end of discharge.
- All tests on the matrix pack with the HAM displayed lower max in general due to the placement of thermocouple on the outside of the HAM rather than on the cells.
- Disconnection of cells has almost no influence on the performance of the packs and does not show any abnormal thermal changes for the 100 cycles obtained in this test program. Longer cycle life may influence the performance especially if the low voltage cell goes into reversal.
- Overcharge leads to CID activation of cells. If the matrix configuration has a larger number of cells in series, (more than 5 S configuration), the limitations of protective devices may manifest itself irrespective of it being in a matrix configuration.
- External short circuit causes a fire with expulsion of content from some cells. The fire does not propagate itself laterally, but if there was cell module stacking, then the fire would cause the cells above it to also go into flames/thermal runaway. Limitations of protective devices are observed in this case as the PTCs in the cells did not protect under this abusive condition.
- Matrix configurations seem to provide protection against lateral propagation of fire and flame.
- Matrix pack configuration seems to provide good performance in spite of losing cell connections;
   at least for the configuration tested under this program.